



**Ensure: Plugs & Sockets colour match & the Gap between coils is more than 60mm (2.5")**

- ① Plug-in antenna to out socket
- ② Pass antenna wire over the front of the water inlet pipe
- ③ Secure with a cable tie
- ④ Tightly coil antenna wire 12 times around the pipe, in the direction of arrows
- ⑤ Secure with a cable tie
- ⑥ Cut cable to size and connect loose antenna plug
- ⑦ Connect plug to socket

Should you have insufficient access to the inlet pipe to fit 2 coils, but enough pipe to fit one coil, even if near a bend or T junction – Install with 1 coil **plugging the antenna into the outer 2 sockets on the unit** – the chances are that it will be 100% effective - you have a money back guarantee.

